

## Instructions for use.

**READ ALL WARNINGS AND DIRECTIONS BEFORE USING THIS PRODUCT**

# The Party Shot™ Confetti System

1. Make certain that the Party Shot™ Unit is empty before loading with Gourmet Confetti™ to prevent any objects heavier than confetti coming down on the heads of your audience or yourself.
2. Take one bag of Gourmet Confetti™ and cut off about 1/2 inch of the bag. Put the open end of the bag into the open end of the Party Shot™ Unit. Lower it in and pour the Gourmet Confetti™ into the Unit by using one hand to hold the bag and the other to hold and tap the Party Shot™ Unit on the ground.
3. By tapping the 'black end cap' of the Unit on the ground it will evenly send the Gourmet Confetti™ to the bottom of the tube.
4. Should a 'clog' occur while loading, cut the other end of the bag open and use the wood Push Rod as a helper. Be sure to remove the bag!
5. By using the Push Rod and tapping, lightly pack the Gourmet Confetti™ down into the bottom of the Unit. Look to see if there are any 'pockets' of open space present - these could hamper the height the confetti will reach. By tapping more while pushing with the Push Rod these 'pockets' of space should disappear. Never force the the Gourmet Confetti™ with the Push Rod.
6. Remove the Push Rod and store. There should only be Leland Gourmet Confetti™ in the Party Shot™ Unit at this time.
7. Take note of the black end cap of the Party Shot™ Unit - It has a threaded 1/2 inch hole, a hex nut, and a pull cord. Before turning in a CO2 cylinder, Note the action of the lever. The lever must travel about 180° degrees outward from the closed position where you start the pull from.
8. Snap the lever with the cord attached back against the housing - this is the starting point. If the lever is away from the housing, sticking out, the CO2 Cylinder will not be activated properly.
9. WARNING A Particle Power™ CO2 Cylinder is under high pressure - It should never be tampered with, heated or mutilated. This type of cylinder is disposable and it is against Federal Law to refill.
10. Turn in one Particle Power™ CO2 Cylinder firmly. IMPORTANT - The Unit is now loaded and ready for your use.
11. It takes a sharp 'tug' to activate the Particle Power™ CO2 Cylinder Therefore take a firm grip of the Party Shot™ unit about 1/2 to 1/3 up from the bottom with one hand and with the other activate the pull cord sharply - It is recommended you hold the main tube against your upper body and use the other hand for the pull cord.
12. Only activate the Party Shot™ Unit in an upright, vertical position, keeping the open end of the unit well above your head. Be prepared for a minor kickback which occurs when firing. **DO NOT TOUCH THE CO2 CYLINDER IMMEDIATELY AFTER FIRING!**  
The cylinder becomes very cold due to the gas escaping rapidly, may cause freezer burns if put against your skin.

**WARNING! READ CAREFULLY BEFORE USE. THIS IS A HIGH POWERED CONFETTI PROJECTILE DEVICE. KEEP FROM CHILDREN UNDER 18. THIS DEVICE IS DESIGNED FOR HAND HELD USE ONLY WITH LELAND GOURMET CONFETTI™. NEVER POINT THE PARTY SHOT™ UNIT TOWARDS PERSONS NEAR BY. PARTICLE POWER™ CYLINDERS CONTAIN CARBON DIOXIDE GAS UN1013-NON-FLAMMABLE GAS.**